



Free Downloads of Build Instructions,  
Assembly Booklets & How To Guides


**[BuildInstructions.com](http://BuildInstructions.com)**

# IMPERIAL<sup>TM</sup> ARMOUR

## PRAETOR ARMoured ASSAULT LAUNCHER 99590105356

### RESIN COMPONENTS LIST

1. FRONT UPPER HULL
2. FRONT HULL
3. LEFT INTERNAL DETAIL
4. RIGHT INTERNAL DETAIL
5. WARHEAD DETAIL 1
6. WARHEAD DETAIL 2
7. FRONT LAUNCHER HOUSING
8. MISSILE RACK 1
9. MISSILE RACK 2
10. LOWER HULL
11. RIGHT TRACK UNIT
12. LEFT TRACK UNIT
13. FUEL DRUMS X2
14. TRACK LINKS X2
15. HEAVY BOLTER SPONSONS X2
16. HATCH COVERS X2
17. INTERNAL BULHEAD DETAIL
18. PISTON
19. PISTON MOUNT
20. TARGETING AUGER DISH
21. TARGETING AUGER MOUNT
22. PISTON MOUNT SIDE
23. LEFT TRACK ARMOUR
24. RIGHT TRACK ARMOUR
25. LAUNCHER
26. REAR HULL
27. PISTON HOUSING
28. FILTER PLATE
29. EXHAUST




This kit contains all the pieces required to make a PRAETOR ARMoured ASSAULT LAUNCHER  
To glue the resin pieces either together or to plastic components use Citadel  
Super Glue.

NOTE: We have cast this conversion kit using the most advanced techniques  
and the best quality resin, but due to the nature of the casting process your  
model may contain very slight air bubbles. These can easily be filled with  
model filler or super glue. Any slight warpage of thin parts can easily be  
corrected by immersing the part in hot tap water for about 1 minute then  
carefully bending it back into shape.



#### THIS IS NOT A TOY

Not suitable for children under 15 years of age.


WARNING: Resin dust can be harmful if inhaled. Always wear a dust  
mask or respirator when sanding or sawing resin parts.



REPEAT FOR BOTH LEFT  
AND RIGHT TRACK UNITS



NOTE THAT ALL EXTERNAL HULL PIECES SHOULD BE GLUED IN PLACE BEFORE PROCEEDING TO  
ATTACH THE OTHER TRACK UNIT



COMPLETED RIGHT TRACK UNIT




ATTACH HEAVY BOLTERS TO FRONT  
SPONSONS BEFORE ATTACHING THE FRONT  
UPPER HULL – DO NOT GLUE THESE IN PLACE.







LAUNCHER PISTON HOUSING

FRONT UPPER HULL



OPTIONAL POSITIONS FOR MISSILE RACKS





PISTON MOUNT SIDE

